




FULLY AUTOMATIC TOP LOADING  
WASHING MACHINE  
**USER'S MANUAL**

**MODEL**

TLA07GP

TLA08GP





Please read this manual carefully before operating your washing machine and retain it for future reference.



# CONTENTS

■ Product overview	1
■ Safety precautions	2
Description of symbols	
Warning	2
Forbidden	3
Safety warning	4
■ Installation & adjustment	5
Install the bottom plate	5
Balance washing machine	5
Usage of the drain hose	6
Inlet pipe connection	6
■ Before washing	9
Check the following before washing	9
■ Operation	10
Loading your laundry	10
Usage of the detergent	10
Explanation of buttons	11
■ Cleaning or Maintenance	14
■ Trouble-shooting	15
■ Packing list	17
■ Specification	18



# Product overview



Please understand the shapes of the washing machine and accessories may be different from the sketch figures in this manual due to product improvement.

# Safety precautions






## Description of symbols

<b>Warning sign</b> 	<p>Contents marked with this symbol are related to the safe use of the product and the personal safety of the user.</p> <p>Please operate in accordance to the contents of this manual, to avoid harm to the user or damage to the machine itself.</p>
<b>Forbidden sign</b> 	<p>Contents marked with this symbol indicate operations or actions that should not be undertaken by the user.</p> <p>Performing of such actions may result in injury to the user or damage to machine itself, and void warranty.</p>

## Safety warning

Please check power socket condition to ensure it has been earthed correctly prior to installation to ensure your safety























### Warning

<p>A separate, earthed power socket is required for the power supply.</p> <p>Hold the plug(not the electric cable)when unplugging the washing machine.</p> <p>Do not insert or remove the power plug with wet hands.</p> <p>The power plug should be accessible after the machine installation.</p> 	<p>Ensure the plug is removed and the taps turned off in the following cases. Power failure, cleaning, moving, installation and when not in use.</p> <p>The new hose-sets supplied with the appliance are to be used, old hose-sets should not be reused.</p> <p>The rated washing capacity, spinning capacity, The max. and min. inlet water pressure refer to specification page.</p> 
<p>This appliance is intended to be used in household and similar applications such as:</p> <ul style="list-style-type: none"> <li>— staff kitchen areas in shops, office and other working environments;</li> <li>— farm houses;</li> <li>— by clients in hotels, motels and other residential type environments;</li> <li>— bed and breakfast type environments;</li> <li>— areas for communal use in blocks of flats or in launderettes.</li> </ul> 	<p>If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.</p> <p> CAUTION: If this appliance is supplied with a cord extension set or electrical portable outlet device, the cord extension set or electrical portable outlet device must be positioned so that it is not subject to splashing or ingress of moisture.</p> 

# Safety precautions



## Forbidden

<p>Do not install this appliance in a damp or wet environment. Do not leave wet laundry on the control panel or spray water directly onto this appliance, as this may cause the washer to malfunction or cause an electrical fault.</p>  	<p>Do not connect to hot water higher than 50°C. For maximum inlet water pressure refer to specification page.</p>  
<p>Do not block the ventilation holes with carpet. Ensure carpet does not obstruct the opening under the base of the cabinet.</p>  	<p>Do not wash water-proof clothing as this may affect load balance during spin cycle(s).</p>  
<p>If you are using an extension cord or a portable electrical outlet device (not recommended), ensure that it is positioned so that it does not come into contact with water or moisture.</p>  	
<p>Do not attempt to move washing or place hands inside washing machine while in operation. Please ensure children are supervised around machine to avoid harm.</p>  	<p>Do not take apart, repair or alter the machine by yourself.</p>  
<p>Do not leave hot or heavy items on lid or control panel as this may cause damage to the washer or make the washer unsafe to operate.</p>  	<p>Do not wash laundry with chemicals or other volatile materials (such as petrol, solvents or thinners) as this causes damage to the machine.</p>  
<p>This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.</p>  	<p>Keep washer away from heat sources such as heater, stoves or direct sunlight.</p>  

# Safety precautions

## Safety warning

The new hose-sets supplied with the appliance are to be used and that old hose-sets should not be reused

Please remove item such as coins, button, sand and other solid materials from clothing before washing.



Check that water faucets are open after connection to machine, prior to operation and that pipes are connected correctly.  
Please use low suds/High Efficiency washing powder.

■ If power cord or other parts of this machine become damaged or faulty, please contact a technician to have it repaired. Do not attempt to repair by yourself as this may cause personal harm or void warranty.

■ Do not let your hands or any other material be caught below door. It might cause injury or damage.

# Installation & Adjustment


Please install and adjust the machine according to the directions contained in this manual. It is very important to follow these directions for the safe operation of the machine and to ensure your machine operates correctly.

## Install the bottom plate

The purpose of the bottom plate is to suppress noise from the washing machine during operation.

Steps:

1. Lay the washer on its back, on a nonabrasive surface.
2. Place the plate onto the bottom of the machine.
3. Use a screwdriver to tighten the screw (in accessory bag) securing the panel to bottom of the washer.
4. Once the screw is tight and the panel is secure, return the washer to its standing position.




## Balance washing machine

Do not install this machine on an incline greater than  $2^{\circ}$ . Installing machine on an angle or on rough ground will result in unstable running or stoppage of the machine. Please adjust it by the following method:

1. Confirm it is level;
2. Lift up the side of the leg slightly and twist the adjustable foot.

Note: The distance between the washing machine and wall: at least 20 mm.




# Installation & Adjustment

## Usage of the drain hose

The drainage shall be smooth with the drain hose.

1. The height of the drain hose shall be less than 10cm, or the drainage will not be smooth, draining will take longer time and the machine may stop mid way.


2. Do not trample or press the drain hose.




3. If the drain hose is too long, cut it at mid point. To make smooth drainage, cut the front end of the hose slantingly.



4. If extra drain hose is needed, please make separate purchase. The inner diameter of the extra hose shall not be less than 30mm, and the length shall not exceed 1.5m.



5. If the extra hose is too long, cut it either at A or at B point.




**Note:** The instructions for appliances connected to the water mains by detachable hose-sets state that the new hose-sets supplied with the appliance are to be used and that an old hose-sets should not be reused.

## Inlet pipe connection


The new hose-sets supplied with the appliance are to be used, old hose-sets should not be reused.

### ■ Confirm the water faucet

water faucet, suitable



water faucet, not suitable



It is required that the front end shall be longer than 10mm.

The exit end face of the faucet shall be flat and smooth. If not please file it to avoid leakage.



# Installation & Adjustment

## ■ Connection between the water inlet hose jointer and the water faucet

1. Press the lower end of the lock lever and push down the slider. Take off the water inlet hose jointer from the water inlet hose component. See to Figure 1.
2. Take off the nameplate. Make sure the threading is 4mm above the upper surface of the knot. See to Figure 6. If the threading is less than 4mm above the upper surface of the knot, please loosen the screws.




Figure 1




Figure 2




Figure 3

3. Loosen the screw till the water faucet can be accessed. Put the jointer of the water inlet hose on the faucet. See to Figure 2. (If the faucet is too large and the jointer can not be set on the water faucet, please loosen the four screws and take out the bushing in the jointer. The front end of the faucet must be smooth, otherwise it may leak water. See to Figure 3.)
4. Fasten the four screws evenly. See to Figure 4.
5. Twist the fastening knot, See to Figure 5. After installation, the threading is less than 2mm above the upper surface of the knot. See to Figure 6.




Figure 4




Figure 5





Figure 6

## ■ Connection between the water inlet hose and the washer


1. Do not take off the water absorption cushion. Please check if the cushion is dropped or damaged before each usage. If it happens please contact our after-sale department immediately.
2. Put the knot of the water inlet hose on the valve jointer.
3. Fasten the knot. Swing it gently to confirm if it's fastened.



# Installation & Adjustment


## ■ Connection between the jointer of the water inlet hose and the water inlet hose

1. Push down the slider. Insert the water inlet hose into the jointer.
2. Hang the lock lever to the jointer. Release the slider till a click sound is heard.




## ■ Check the connection between the jointer of the water inlet hose and the water faucet

1. Shake the hose gently to confirm if it is well fastened.
2. After installation, open the faucet to check if it leaks.
3. Do not bend the hose with overstrain.
4. Before each usage please check if the connection between the jointer of the water inlet hose and the water faucet, and the installation of the water inlet hose are firm, so as to prevent water spillage from improper installation position.



## ■ Dismantling the water inlet hose

1. Close the water faucet.
2. Press the lock lever. push down the slider then pull off the water inlet hose. If the machine is used frequently, the jointer of the water inlet hose maybe left permanently connected.




# Before washing



## Preparation before washing

1. Connect the water inlet hose. Open the water faucet.
2. Then insert the power plug into the receptacle. To ensure that the washing machine works properly, the voltage range should be between 187-253V.
3. Put down the drain hose.



## Check the following before washing

Clear the pockets and take out loose items such as coins, sand, hairpins, etc.



Tie any long straps or strings, fasten buttons and close zippers.



The weight of the laundry shall not exceed the rated capacity of your machine, loosen the laundry before placing it evenly in the tub.



When the machine is running, buttons may cause noise.

To reduce the noise, turn clothes inside out or place them in a laundry bag.



- a. Check if the laundry has any special washing instructions.
- b. Divide the laundry into colour and non-colour items.
- c. Separate items that do not absorb water easily and wash by hand.
- d. For heavily soiled items, please first remove loose dirt, then apply detergent directly (as per instructions on pack) to the stain before washing.
- e. For those items that may attract lint or are furry or fluffy, please turn inside out before washing.
- f. Do not put laundry soiled with chemicals or solvents into the washing machine.

# Operation

## Loading your laundry



- The rated washing capacity refers to the largest dry weight of a load that can be washed.
- The thickness, size and type of clothes will influence the actual capacity.
- Do not select more than water level “36L” for clothes less than 1.0kg, to avoid splashing of water.
- It is recommended that low suds/high efficiency washing powder should be used.

## Usage of the detergent

### How to use washing powder


- It is suggested to dissolve detergent before adding to the tub, see as below: It is suggested
  1. Prepare warm water (<35°C) in a container.
  2. Add washing powder, stirring to dissolve it completely.
- Adding washing powder Normal Wash

It is recommended that washing powder/liquid is dissolved with water and then directly emptied into the washing machine:

  1. Add some water (select the “18L” water level)
  2. Add washing powder/liquid. Run for about 30 seconds to fully dissolve the detergent. Then press the “Start/Pause” button to pause the wash cycle.
  3. Load laundry. Select suitable water level. Press the “Start/Pause” button again to recommence washing cycle.
- If you select “Quick Wash” program, it is recommended to use liquid detergent instead of washing powder to ensure the most effective wash results.
- Old or poor quality washing powder may cause caking in tub or detergent dispenser.
- Clean the detergent box periodically to ensure washing power is evenly distributed and remove any detergent build up.
- When water pressure is too low, it is possible that washing powder or washing liquid cannot be washed away effectively, and washing powder or washing liquid would be agglomerated after a period of time. Please clean the detergent box in time. It is recommended to pour the washing powder or liquid into the basket directly.

# Operation

## Explanation of buttons



### Indicator display

- Off
- On: Indicates the program is about to run and indicates the selected cycle and options
- Flashing: Indicates the program is running and indicates the selected cycle and options

### Child Lock function

- The function is intended for children's safety and preventing children from accidental changes to washing programs.
  - Press Power button, set the desired washing program, after setting, press Start/Pause button, then press Water Level button and Delay button at the same time and hold for 3 seconds, The digitron displays "CL", the child lock will activate. All of the buttons are locked and have no function.
  - Release the child lock function: In the process of program running, Press Water Level button and Delay button at the same time and hold for more than 3 seconds. After three beep sound, the child lock function is release. The child lock light goes out.
- NOT: If you open the lid when the "Child Lock" is activated, digital tube display "E2" and beep, you need close the lid and press the "Start/Pause" to cancel, or washing machine will drain after 10 seconds.



Child Lock

### Digital tube

- During working, it displays the remained reserve time (minute). In case of trouble, it displays the abnormal symbol (see to page 15)
- During reserve, it displays the remained reserve time (hour).

Page 15




Power

### "Power" button


- Press the "Power" button to switch on the power.
- Under power-on mode, press it to switch off the power.
- If the "Start/Pause" button is not pressed, the machine will switch off the power automatically after 5 minutes.

# Operation


Start/Pause


**"Start/Pause" button**

- After the power is switched on, press it to start the machine.
- During working, press it to pause.
- During pause, press this button to restart and go on working.


Delay


**"Delay" button**

- During operation, the digitron tube will display the remained time (hours). Push down the delay button. The delay indicator light is on, the digitron displays the delay time of finishing washing (in hour). The point light flashes to indicate in the reverse mode.


Cycle

**"Cycle" select**

Program	Application
Wash	Just run the washing cycle without drainage cycle. The detergent water will be left in the tub, so water can be reused.
Rinse	Remove the left detergent from the clothes and then rinse the clothes
Spin	Start extraction program when the wash program ends or the clothes are wet
Tub Dry	The purpose is drying the inner tub after wash cycle in order to prevent mildew or bacteria growing in the wash environment.
Normal	Recommended for mixed fabrics and general clothing items
Soak	Washing relatively big thick or very dirty laundries
Delicate	Program for washing lightly soiled or delicate clothes such as Baby or Ankara clothes,
Quick Wash	Quick wash suitable for a small amount of slightly soiled clothes


Water Level

**"Water Level" button**


- Using Normal program, the washing machine can detect the size of load, select the water level automatically between 36L, 48L, 60L and start washing by a simple One-Touch push of Start/Pause button.
- User can select the water level by themselves, if need to adjust water level after operation, need to press start/pause first, then can select water level.
- If there is water inside the tub, machine can not detect the laundry size, it will display water level "36L". If add wet laundry, it may display water level "60L", you can select suitable water level by yourself.
- During operation of wash or rinse program, you can add water by keep pressing water level button, release pressing, will stop input water.
- The displayed water level maybe different with the actual water level due to the different moisture of laundry.

# Operation

## Button Operation and Descriptions

1. Push the  Power button to switch on the power



2. Push the  button to select suitable automatic program




After the power is switched on, "Normal" is automatically set. To select other fully-auto program, please push the "Cycle" button till the corresponding indicator is light. Refer to the "Cycle" button on Page 12.

For an example: select Quick Wash for the quick washing of the laundries with light dirt.



3. Push the  button, select suitable water level



After switching on the power, when the normal program is selected, the washing machine will execute fuzzy program automatically to detect the cloth. After detection, it can set the water level automatically. To select other water level, first push the "Start/Pause" button, then push the "Water Level" button to set the water level.

4. Push the  button to select suitable reserve wash program



After switching on the power, the reserve time program is set to off mode automatically. If you need to set the washing procedure to be finished at delay time, please push the "Delay" button to set the reserve washing program. Refer to delay button in Page 12 for selection.

- Confirm the reserve program




- When the "Delay" function is activated, the indicator light of the program you have set will be off. The "Delay Time" and "Remaining Time" indicator lights will be on.

The washing will finish about 18 hours later

- During reserve procedure, push the "Delay" button to display the relay mode.

- To change the running program or cancel the relay setting, you need to switch off the power and make new selection.

5. Push the  Start/Pause button, close the top lid



If the top cover is opened, the washing machine will stop running and tweet during spinning, then close the lid, you must push the Start/Pause again to continue running.

## Cycle completed


When the machine has completed the selected/current wash cycle an audible alarm will sound and the machine will switch off automatically.

# Cleaning or Maintenance

## Maintenance


- Remove the power plug before carrying out any cleaning or maintenance.
- Clean the lint filter(s) and detergent box after each wash.

The filter at the water inlet valve may become blocked by impurities in the water supply. Clean it with a plastic bristled brush every two months.



If the cabinet is dirty, wipe it with a damp cloth


- Do not wash directly with water.
- Wipe with a neutral detergent (please check directions on detergent bottle first).
- Do not wipe machine with thinners, petrol, alcohol or other harsh solvents.




- The lint filter must be used during washing.
- It must be cleaned in time after each use.

The methods of dismantling and installing the lint filter is as follows;

1. Press the spring piece of the top lint filter to bring the claws out of the filter cover, and then pull out the lint filter to get it down. (figure 1).
2. Pull the lint filter apart or upward as shown in (figure 2) below to open the front cover of the filter.
3. Sweep the lint in the lint filter.
4. Put the back of the lint filter into the front cover.
5. Put the lint filter into filter cover, and make it tight.
6. Make sure the lint filter is well installed, otherwise it can affect the machine's performance.



**Figure 1**



**Figure 2**

Sample:TLA08GP

1. After washing cycle has finished, turn off the water faucet. (If needed, you can remove the water inlet hose).
2. Do not store water in the washing machine for a long period without completing a wash cycle. Drain the water completely after each wash.
3. Hang up the power cord and drain hose.
4. Wipe off any drops of water on the surface of the machine and inside the tub. Leave the lid open for about 1 hour after each wash to evaporate any residual water.



# Trouble-shooting

If there is a fault or the machine does not operate correctly, remove the power plug before checking the machine. Using diagnostic list below, please check if the machine requires repair. If a repair is required, please contact our customer care team, do not try to fix it by yourself.

Problem		Possible causes	What to do
The machine does not drain or drain slowly. The display shows E1.		■ Is the drain hose blocked?	■ Remove the blockage. Press Start/Pause button once more.
The machine stops running The display shows E2.		■ The top lid is not closed.	■ Close the top lid. Press the Start/Pause button once more.
The machine does not spin The display shows E3.		■ Has the laundry been placed unevenly in the machine? ■ Is the machine standing on a leveled surface above the ground?	■ Redistribute the load evenly. Press the Start/Pause button once more. ■ Level the machine.
The display shows E4.		■ Is the water tap closed or has the water supply been interrupted? ■ Is the water inlet valve blocked? ■ Is the water pressure too low?	■ Turn on the water tap. Press Start/Pause button once more. ■ Clean the water inlet valve then press the Start/Pause button once more. ■ Use after the water pressure is normal.
The display shows FA.		■ The water level sensor has failed.	■ Please contact Customer Care.
The machine does not work.	Will not wash	■ Is there a power failure? ■ Is the power plug inserted tightly? ■ Has the water level reached preset position?	■ Wait for the power supply to be restored. ■ Insert the power plug tightly. ■ Wait for the water to fill to the preset level
	Will not spin	■ Is the power plug inserted tightly? ■ Is the top lid closed? ■ Is the laundry distributed unevenly in the machine?	■ Insert the power plug tightly. ■ Close the top lid. Press the Start/Pause button once more. ■ Redistribute the laundry.
There are abnormal sounds inside the machine.		■ Is the machine level? ■ Has the laundry been placed unevenly in the machine? ■ Are there any foreign objects inside the bowl?	■ Level the machine. ■ Redistribute the load evenly. Close the top lid. Press the Start/Pause button once more. ■ Remove the foreign objects.

# Trouble-shooting

Problem	Possible causes	What to do
The water tap leakage.	■ Is the water inlet hose loose?	■ Fasten the inlet hose.
The display shows F2.	■ Indicates water has reached a critical level.	■ Please contact Customer Care.

## Common occurrence

Situation	Cause
■ The spinning is intermittent after it starts.	■ Redistribute the load evenly. Close the top lid.
■ Select spin program, but it does not work.	■ The program is setting the drain time, there will be a pause before the spin program starts.
■ There maybe water in the drain hose when first used.	■ It may be residual water after performance inspection by the factory.
■ There wash procedure pauses.	■ The cloth sensor is detecting, it will add water after about 48 seconds.
■ When the power plug is inserted, computer board indicator is switched on, and the machine starts working.	■ It is the special resume function. In the case of power failure or the power plug is loose during washing, the machine can save the running program, and resume the program after the power supply is recovered. You donot need to set the program again.

# Packing list

Name	Quantity	Storage position
■ Automatic washing machine	■ One	
■ Bottom plate	■ One	■ Placed in the upper foam piece inside the washing machine packaging
■ User manual	■ One	■ Inside the document bag
■ Warranty card	■ One	■ Inside the document bag
■ Screw	■ One	■ Inside accessory bag
■ Components of the water inlet hose	■ One	■ Inside accessory bag

# Specification

Type	Fully Automatic Washing Machine	
Model	TLA08GP	TLA07GP
Rated voltage/frequency	230V/50Hz	
Rated washing power	400W	390W
Rated spinning power	300W	265W
Net weight	30.5kg	26kg
Gross weight	34.5kg	30kg
Dimensions(mm)	W 520 D 540 H 918	W 500 D 520 H 902
Water inlet pressure	0.03MPa-1.0MPa	
Rated Washing capacity	8.0kg	7.0kg